



## **SPATIQUE “FROG” System Chemical Recipe**

### **New Spa Initial Fill or Existing Spa Refill**

**Step 1: Test H2O & adjust Ph & Total Alkalinity AS NEEDED.**

**Step 2: Add 8 oz. of SPA BRIGHT (Removes Unwanted Minerals)**

**Step 3: Add 1 oz. of CONTROL (Mineral Control & Clarifier)**

**ALL SPAS WAIT 6 HOURS BEFORE PROCEEDING TO STEP 5**

**Step 4: Install BLUE FROG & YELLOW FROG Cartridges in housing.**

**Step 5: Add 2 oz. BROM START. (Establishes Bromine Reserve.)**

**Step 6: Add 2 oz. SPA SHOCK. (Activates Brom Start)**

### **Weekly Spa Chemical Maintainece**

**Step 1: Test For Bromine, Ph, & Alkalinity- Adjust As Needed.**

**Step 2: Check FROG BROMINE Cartridge. Replace As Needed.**

**Step 3: Add 2 oz. SPA SHOCK.**

**Step 4: Add 1 oz. CONTROL.**

**Step 5: Add 1oz. 5-IN-1 CLARIFIER. (For Optimum Water Clarity.) (OPTIONAL)**

**Step 6: Add 1oz. SCUM OUT (OPTIONAL)**

***\*FOR SPAS USED 3+ TIMES WEEKLY, ADD SPA SHOCK 2 X WEEKLY. \****

## **RECOMMENDED ROUTINE SPA/CHEMICAL MAINTAINCE**

- 1. Replace BLUE MINERAL Cartridge Every 4 Months.**
- 2. Clean Filters Monthly With Pressure Hose Spray.**
- 3. Clean with SPRAY CARTRIDGE CLEANER After each Drain.**
- 4. Drain/Refill Spa 2-4 X a Year; Avoid Doing During Freeze.**
- 5. To Boost Low Bromine Level- Add 2 oz. BROM START Then Wait 5 Minutes & Add 4 oz. SPA SHOCK.**
- 6. For Unsightly Or Foul-Smelling Water; Consider: Is H2O Due To Be Drained? Are Filters In Need Of Changing/Cleaning? Increase Duration or Frequency Of Filtration Run Cycles.**