



SPATIQUE “FROG” System Chemical Recipe

New Spa Initial Fill Or Existing Spa Refill

- Step 1: Test H2O & adjust Ph & Total Alkalinity AS NEEDED.
- Step 2: Add 8 oz. of SPA BRIGHT (removes unwanted minerals)
- Step 3: Add 1 oz. of CONTROL (Mineral Control & Clarifier)

ALL SPAS WAIT 6 HOURS BEFORE PROCEEDING TO STEP 4.

- Step 4: Install BLUE FROG & YELLOW FROG Cartridges in housing.
- Step 5: Add 2 oz. BROM START. (Establishes Bromine Reserve.)
- Step 6: Add 2 oz. SPA SHOCK. (Activates Brom Start.)

Weekly Spa Chemical Maintenance

- Step 1: Test For Bromine/ Ph & Alkalinity- Adjust As Needed.
- Step 2: Check FROG BROMINE Cartridge, Replace As Needed.
- Step 3: Add 2 oz. SPA SHOCK.
- Step 4: Add 1 oz. CONTROL
- Step 5: Add 1oz. 5-IN-1 CLARIFIER. (For Optimum Water Clarity.)

FOR SPAS USED 3+ TIMES WEEKLY, ADD SPA SHOCK 2X WEEKLY.

Recommended Routine Spa/Chemical Maintenance

1. Replace BLUE MINERAL Cartridge Every 4 Months.
2. Clean Filters Monthly With Pressure Hose Spray.
3. Clean with SPRAY CARTRIDGE CLEANER After Drain.
4. Drain/Refill Spa 2-4 times per Year; Avoid Doing During Freeze.
5. To Boost a Low Bromine Level- Add 2 oz. BROM START Then Wait 5 Minutes & Add 4 oz. SPA SHOCK.
6. For Unsightly Or Foul-Smelling Water; Consider: Is H2O Due To Be Drained? Are Filters In Need Of Changing/Cleaning? Increase Duration and/or Frequency Of Filtration Run Cycles.