

SPATIQUE “Bromine” Chemical Recipe

New Spa Initial Fill Or Existing Spa Refill (based on 500 gal)

Step 1: Test H2O & adjust Ph & Total Alkalinity AS NEEDED.

Step 2: Add 8 oz. of SPA BRIGHT (any size spa) if hard water.

Step 3: Add 2 oz. of CONTROL (Mineral Control & Clarifier)

ALL SPAS WAIT 6 HOURS BEFORE PROCEEDING TO STEP 5

Step 4: “TURN SPA OFF” Open filter lid to access Bromine feeder & fill feeder ³/₄ full with Bromine. (BROM TABS) “TURN SPA ON.”

Step 5: Add 2 oz. BROM START. (Establishes Bromine Reserve.)

Step 6: Add 6 oz. SPA SHOCK. (Activates Bromide.)

Step 7: Add 6 oz. PH HOLD. (Ph Stabilizer & H2O Softner. (OPTIONAL)

Weekly Spa Chemical Maintenance

Step 1: Test For Bromine/ Ph & Alkalinity- Adjust As Needed.

Step 2: “TURN SPA OFF” Refill Bromine Feeder With BROM TABS.

Step 3: “TURN SPA ON” Add 2 oz. SPA SHOCK.

Step 4: Add 1 oz. CONTROL.

Step 5: Add 1oz. SCUM OUT. (OPTIONAL)

Step 6: Add 1 oz. 5-IN-1 CLARIFIER. (For Optimum Water Clarity.) (OPTIONAL)

FOR SPAS USED 3+ TIMES WEEKLY, ADD SPA SHOCK 2 X WEEKLY.

RECOMMENDED ROUTINE SPA/CHEMICAL MAINTAINCE

1. Clean Filters Monthly with Pressure Hose Spray.
2. Clean with Spray Cartridge Cleaner After each drain & fill.
3. Drain & Refill Spa 2 to 4 Times a Year; Avoid Doing During Freeze.
4. To Boost Low Bromine Levels- Add 2 oz. BROM START Then Wait 5 Minutes & Add 4 oz. SPA SHOCK.
5. For Unsightly Or Foul-Smelling Water; Consider: Is H2O Due To Be Drained? Are Filters In Need Of Changing or Cleaning? Increase Duration or Frequency of Filtration Run Cycles.