

SPA TIQUE' "Bromine" Chemical Recipe

New Spa Initial Fill Or Existing Spa Refill (based on 500 gal)

- Step 1: Test H2O & adjust Ph & Total Alkalinity AS NEEDED.
- Step 2: Add 8 oz. of SPA BRIGHT (any size spa) if hard water.
- Step 3: Add 2 oz. of CONTROL (Mineral Control & Clarifier)
- Step 4: Add 4 oz. of SCUM OUT (Helps to reduce Scum line)

ALL SPAS WAIT 6 HOURS BEFORE PROCEEDING TO STEP 5

- Step 5: "TURN SPA OFF" Open filter lid to access Bromine feeder & fill feeder $\frac{3}{4}$ full with Bromine. (BROM TABS) "TURN SPA ON."
- Step 6: Add 2 oz. BROM START. (Establishes Bromine Reserve.)
- Step 7: Add 6 oz. SPA SHOCK. (Activates Bromide.)
- Step 8: Add 6 oz. PH HOLD. (Ph Stabilizer & H2O Softner.)

Weekly Spa Chemical Maintenance

- Step 1: Test For Bromine/ Ph & Alkalinity- Adjust As Needed.
- Step 2: "TURN SPA OFF" Refill Bromine Feeder With BROM TABS.
- Step 3: "TURN SPA ON" Add 2 oz. SPA SHOCK.
- Step 4: Add 1 oz. CONTROL.
- Step 5: Add 1oz. SCUM OUT.
- Step 6: Add 1 oz. 5-IN-1 CLARIFIER. (For Optimum Water Clarity.)

FOR SPAS USED 3+ TIMES WEEKLY, ADD SPA SHOCK 2 X WEEKLY.

Recommended Routine Spa/Chemical Maintenance

1. Clean Filters Monthly With Pressure Hose Spray.
2. Clean " W/ SPRAY CARTRIDGE CLEANER After Drain.
3. Drain/Refill Spa 2-4 X a Year; Avoid Doing During Freeze.
4. To Boost A Low Bromine Level- Add 2 oz. BROM START Then Wait 5 Minutes & Add 4 oz. SPA SHOCK.
5. For Unsightly Or Foul-Smelling Water; Consider: Is H2O Due To Be Drained? Are Filters In Need Of Changing/Cleaning? Increase Duration &/Or Frequency Of Filtration Run Cycles.